


# MICRO

## Spare Parts List



**SPARE PARTS LIST****MICRO**

<b>Pos</b>	<b>Description</b>	<b>Part no</b>	<b>Notes</b>
1	Housing assy.	399 S 30060	
2	Sealing	399 08800	
3	Lock	399 14810	
4	----	----	
5	----	----	
6	----	----	
7	Belt assy.	399 S 13400	
8	3-way-valve	399 49200	
9	Angle coupling	399 08000	
10	Adapter	399 74650	
11	Angle coupling	399 89000	
12	Hose nipple	399 79500	
13	Sealing washer	399 02880	
14	Bushing	399 06600	
15	Compr.air hose	399 86500	
16	Hose clamp	399 78600	
17	Adapter	399 80100	
18	Nozzle	399 55600	4,5mm
19	Diffuser 2" assy.	399 S 11500	
20	----	----	
21	Filter 600mm	399 15120	2 Pcs
22	----	----	
23	Hose clamp	399 78800	
24	Suction hose 2"	399 83000	
25	Swivel	399 75600	
26	Pick-up-hood assy.	399 S 82950	
27	Split pin	399 74500	
28	Washer	399 02960	
29	Pick-up-hood upper	399 82900	
30	Gasket	399 71400	
31	Pick-up-hood lower	399 82800	
32	Bracket stay	399 S 8601	
33	Plastic bag	399 72500	
35	Top cover	399 50000	
36	Filter tool	399 15600	